

**CDE**

# **User Guide**

# **CDE**

**VARIABLE SPEED DRIVE**

for  
**STANDARD AC INDUCTION MOTORS**  
0.75kW to 11kW



## Safety Information

Persons supervising and performing the electrical installation or maintenance of a CDE Drive must be suitably qualified and competent in these duties. They should be given the opportunity to study and if necessary to discuss this User Guide before work is started.

The voltages present in the CDE Drive are capable of inflicting a severe electric shock and may be lethal. The Stop function of the CDE Drive does not remove dangerous voltages from the CDE Drive terminals. Mains supplies should be removed before any servicing work is performed.

The installation instructions should be adhered to. Any questions or doubt should be referred to the supplier of the equipment. It is the responsibility of the owner or user to ensure that the installation of the CDE Drive and the way in which it is operated and maintained complies with the requirements of the Health and Safety at Work Act in the United Kingdom and applicable legislation and regulations and codes of practice in the UK or elsewhere.

The CDE Drive software incorporates an optional Auto-start facility. In order to prevent the risk of injury to personnel working on or near the motor or its driven equipment and to prevent potential damage to equipment, users and operators, all necessary precautions must be taken if operating the CDE Drive in this mode.

The Stop and Start inputs of the CDE Drive should not be relied upon to ensure safety of personnel. If a safety hazard could exist from unexpected starting of the CDE Drive, an interlock should be installed to prevent the motor being inadvertently started.

## General Information

The manufacturer accepts no liability for any consequences resulting from inappropriate, negligent or incorrect installation or adjustment of the optional operating parameters of the equipment or from mismatching the CDE Drive with the motor.

The contents of this User Guide are believed to be correct at the time of printing. In the interests of a commitment to a policy of continuous development and improvement, the manufacturer reserves the right to change the specification of the product or its performance, or the contents of the User Guide, without notice.

All rights reserved. No part of this User Guide may be reproduced or transmitted in any form or by any means, electrical or mechanical including photocopying, recording or by any information storage or retrieval system, without permission in writing from the publisher.

Copyright © 1998 Control Techniques Ltd

Part Number **0427-0013**

CDE Issue 3    May 1998



CONTROL TECHNIQUES DRIVES LTD  
79 MOCHDRE INDUSTRIAL ESTATE  
NEWTOWN, POWYS SY16 4LE

### DECLARATION OF CONFORMITY

The AC variable speed drive product bookcase CDE power range 0.75kW-2.2kW, 4.0kW-7.5kW, and 11.0kW, has been designed and manufactured in accordance with the following European harmonised, national and international standards:

EN60249	Base materials for printed circuits
IEC326-1	Printed boards: General information for the specification writer
IEC326-5	Printed boards: Specification for single and double sided printed boards with plated through holes
IEC326-6	Printed boards: Specification for multilayer printed boards
IEC664-1	Insulation co-ordination for equipment within low-voltage systems: Principles, requirements and tests
EN60529	Degrees of protection provided by enclosures (IP code)
UL94	Flammability rating of plastic materials

This product complies with the Low Voltage Directive 73/23/EEC and the CE Marking Directive 93/68/EEC.

W. Drury  
Technical Director

Newtown  
Date: 13 January 1997

#### Note

This electronic drive product is intended to be used with an appropriate motor, controller, electrical protection components and other equipment to form a complete end product or system. It must only be installed by a professional assembler who is familiar with requirements for safety and electromagnetic compatibility ("EMC"). The assembler is responsible for ensuring that the end product or system complies with all the relevant laws in the country where it is to be used. Refer to the product manual or EMC data sheet for further information on EMC standards complied with by the product, and guidelines for installation.

Steve Leyland  
13/01/97

Rev.0  
Issue C



Worked Example 1: Specify a thermal overload for use with a DB140 using its internal resistor. The application is working the resistor close to its maximum specification of 1.5kW for 10 seconds, with 90 seconds cooling time. The nominal resistance is 80Ω.

Data:

$P_{max} = 1.5kW$   
 $t_{max} = 10 \text{ seconds}$   
 $R = 80\Omega$   
 $V_{dc} = 750V$

Since the continuous rating of the resistor is 150W the average current must be limited to

$$\sqrt{\frac{150}{80}} = 1.369 \text{ Amps}$$

$$I_{pk} = \frac{750}{80} = 9.375 \text{ Amps}$$

$$\text{Duty} = \frac{1.369}{9.375} = 0.146$$

$$I_{rms} = \sqrt{9.375^2 \cdot 0.146} = 3.582 \text{ Amps}$$

$$I_{set} = \frac{3.582}{4} = 0.895 \text{ Amps}$$

This is the current that must be set on the relay so relay type LR2-D1306 (1.0A to 1.6A) should be used.

The short circuit condition will overload the relay by a factor of 8.5, and this will cause the relay to trip out after approximately 4 seconds.

The diagrams below cover the following drives

Vector	CDE	Digitax	Spindax
VBE400	CDE400	DBE420	SA010
VBE550	CDE550	DBE600	SA016
VBE750	CDE750	DBE750	SA022
VBE1100S	CDE1100S	DBE1100S	


**Electrical Installation**

The following diagrams show how to connect the relay to protect the internal resistor for the drives stated, or external resistors if used.




Large bookcase package

Internal Resistor




External Resistor




The internal resistor must be disconnected if an external resistor is being used. The internal resistor is disconnected if there is no connection between the two way terminal block on the bottom of the unit.

Small Bookcase Package Only

Internal Resistor Protection



External Resistor Protection



NOTE: If external resistors are used, ensure that the internal resistor is disconnected by removing any wire link between terminals 3 and 5.



Addendum to: Bookcase Digitax, Spindax, CDE, Vector

Issue Code: spux1, dgxu2

The previous diagrams refer to the following drives:

Vector	CDE	DigitAx	SpindAx
VBE75	CDE75	DBE140	SA005
VBE110	CDE110	DBE220	
VBE150	CDE150		
VBE220	CDE220		

The normally closed contacts 95 and 96 should be connected in series with the line contactor coil.

# Data

## Ingress Protection

IP20 including cooling fans when fitted

## Power supply

380V - 480Vac  $\pm 10\%$  at 60Hz  $\pm 2$ Hz

380V - 440Vac  $\pm 10\%$  at 50Hz  $\pm 2$ Hz

Supply impedance: 0 $\Omega$  min.

Maximum supply imbalance:  
2% negative phase sequence equivalent to  
3% phase voltage imbalance

## Output Ratings

### Output type

3-phase balanced asynchronous PWM synthesised sine wave

### Output voltage

Variable from 0V to a maximum value that is nominally equal to the supply voltage

### Output frequency

Fully variable from: 0Hz to 1kHz

Accuracy: 0.01% of O/P frequency signal

Resolution:

Keypad control

0.1Hz up to 100Hz

1Hz above 100Hz

High resolution mode

0.001Hz

### Maximum output current

150% of full load current for 60 seconds

## Environment

### Operating ambient temperature

-10°C to +50°C

### Storage temperature and time

-40°C to +50°C, 12 months maximum

### Maximum Humidity

Non condensing

## Derating

If the site is above 1000m, reduce the normal full-load current by 1% for each 100m above 1000m.

Local heat sources (such as other equipment) that raise the air temperature above +50°C must be removed.

## Starts per hour

### CDE Drive

By switching the supply: 20 starts per hour maximum

Electronic control only: unlimited

### Motor

Refer to the motor manufacturer

## PWM switching frequencies

The switching frequency can be selected from:

3kHz, 6kHz, 9kHz, 12kHz

The selected frequency remains constant for all drive frequencies, unless quasi square-wave is selected (using parameter **b6.24**).

## Weight

Model	kg
CDE 75, 110, 150	5.0
CDE 220	5.5
CDE 400	7.5
CDE 550, 750	8.0
CDE 1100	9.0

## Power ratings

Model CDE	Motor power		Maximum continuous output current A	Input current A	Maximum input power at 415V kVA	Maximum output power at 415V kVA
	HP	kW				
75	1.0	0.75	2.1	3.4	2.4	1.5
110	1.5	1.1	2.8	4.5	3.2	2.0
150	2.0	1.5	3.8	5.5	4.0	2.7
220	3.0	2.2	5.6	8.7	6.3	4.0
400	5.0	4.0	9.5	13.2	9.5	6.8
550	7.5	5.5	12.0	13.5	9.7	8.6
750	10.0	7.5	16.0	16.7	12.0	11.5
1100	15.0	11.0	22.0	23.4	17.0	16.0

## Fuses and power cables

### Fuses

The use of a 'slow' fuse is recommended for handling current surge during power-up of the CDE Drive.

### Cables

Sizes given are for 3-core and 4-core PVC-insulated armoured cable rated at 600Vac (1000Vdc) and laid in accordance with the manufacturer's instructions.

Model	Recommended fuse rating at 380V A	Typical cable size mm <sup>2</sup>
CDE 75	6	1.0
CDE 110	6	1.0
CDE 150	10	1.5
CDE 220	10	1.5
CDE 400	16	2.5
CDE 550	16	2.5
CDE 750	20	2.5
CDE 1100	35	4.0

## Control signal wiring

Recommended size: 0.5mm<sup>2</sup> or 20AWG.

Overall screen required.

Connect screen only to the 0V terminal on the CDE Drive.

## Braking resistor

Model	Max regenerative power with internal braking resistor	Minimum external resistor value
CDE 75	1.5kW for 10 secs braking time with 90 secs minimum cooling time	80Ω
CDE 110		
CDE 150		
CDE 220		
CDE 400	3.0kW for 10 secs braking time with 90 secs minimum cooling time	40Ω
CDE 550		
CDE 750		
CDE 1100		

## Heat dissipation and cooling

Model	Drive Heat Dissipation		Cooling method
	at 3kHz PWM W	at 12kHz PWM W	
CDE 75	45	68	Natural
CDE 110	53	85	
CDE 150	62	95	
CDE 220	95	145	
CDE 400	140	248	Fan
CDE 550	175	300	
CDE 750	230	392	
CDE 1100	260	470	

## Serial Communications

RS485, RS422 – 4.8, 9.6, 19.2k Baud


Protocol: ANSI x3.28-2.5-A4-N, positive logic



# Mechanical Installation

## Mounting location

- 1 Choose a location that is free from excessive dust, corrosive vapours, gases and all liquids, including condensation of atmospheric moisture.
- 2 If condensation is likely to occur when the CDE Drive is not in use, install an anti-condensation heater. This heater must be switched off when the CDE is in use; automatic switching is recommended.
- 3 Do not locate the CDE Drive in a classified hazardous area, unless the CDE Drive is installed in an approved cubicle and the installation is certified.
- 4 Install the CDE Drive vertically for best flow of cooling air.
- 5 Observe the requirements for ambient temperature if the CDE Drive is to be mounted directly above any heat generating equipment (such as another CDE Drive). The CDE Drive has over-temperature protection which trips the Drive when the heatsink reaches 90°C.
- 6 If the CDE Drive is to be installed directly beneath other equipment (such as another variable speed drive), ensure the CDE Drive does not cause the ambient temperature requirements of the equipment to be exceeded.
- 7 Leave 3mm clearance to the side of the CDE Drive to allow removal of the terminal cover.
- 8 When mounting the CDE Drive close to other equipment, leave a minimum clearance of 100mm above and below.
- 9 The CDE Drive can be surface or through-mounted on a panel or in a sealed or ventilated cubicle.




## Installing the CDE Drive


The CDE Drive may be installed in either of these mounting arrangements:

Surface mounted on a panel or in a cubicle


Through an aperture in a panel so that the heatsink of the CDE Drive projects from the rear of the panel. This arrangement can be used for mounting the CDE Drive through the rear panel of a cubicle to allow free circulation of air around the heatsink and to minimise temperature rise inside the cubicle. This can be beneficial if the cubicle is to house a number of CDE Drives.



- |         |          |
|---------|----------|
| CDE 75  | CDE 400  |
| CDE 110 | CDE 550  |
| CDE 150 | CDE 750  |
| CDE 220 | CDE 1100 |



Dimensions		CDE 75	CDE 400
		CDE 110	CDE 550
		CDE 150	CDE 750
		CDE 220	CDE 1100
Height of case	h	352	352
Width	w	78.5	127
Overall Depth	d	323.5	328.5
Depth of heatsink	p	95	100
Surface mounting fixing centres top bracket to bottom bracket	a	359.4	359.4
Through-panel mounting fixing centres top bracket to bottom bracket	b	372	372
Width of mounting bracket	g	60	92
Fixing centres of mounting bracket	f	45	77
Inset of mounting bracket from side of case	e	9.25	17.5
Fixing hole diameter		4mm clear	



The CDE Drive is held in place by two brackets fixed with self-tap screws to the top and bottom of the unit. The brackets can be re-positioned to suit either mounting arrangement shown above. To re-position the brackets, remove their retaining screws and re-fit the brackets in the required location.

### Installing in a sealed cubicle

To maintain sufficient cooling of the CDE Drive when it is installed inside a sealed cubicle, heat generated by all the equipment in the cubicle must be taken into account and the cubicle must be of adequate size. To calculate the minimum acceptable size of cubicle, use the following procedure.

Calculate the minimum required surface area  $A_e$  for the cubicle from:

$$A_e = \frac{P}{k(T_i - T_{amb})}$$

where...

- $A_e$  Unobstructed heat-conducting area in  $m^2$
- $k$  Heat Transmission coefficient of the cubicle material
- $T_i$  Maximum permissible operating temperature in  $^{\circ}C$  of the CDE Drive
- $T_{amb}$  Maximum external ambient temperature in  $^{\circ}C$
- $P$  Power in Watts dissipated by all heat sources in the cubicle.

### Example

To calculate the size of a cubicle for one CDE 750 (7.5kW). The following conditions are assumed:

The installation is to conform to IP54, the CDE Drive being surface-mounted within the cubicle.

Only the top, front and two sides of the cubicle are free to dissipate heat.

The cubicle is to be made of painted 2mm sheet steel.


The maximum external ambient temperature is  $30^{\circ}C$ .

The CDE Drive PWM frequency is 3kHz.

Insert the following values:

$P = 230W$  (from **Heat Dissipation and Cooling** table in *Data*)

**Note** It is essential to include any other heat sources in the value of  $P$ .



$$T_i = 50^\circ\text{C}$$

$$T_{amb} = 30^\circ\text{C}$$

$k = 5.5$  (typical value for painted 2mm sheet steel)

The minimum required heat conducting area is then:

$$A_e = \frac{230}{5.5(50 - 30)} = 2.09\text{m}^2$$

The unobstructed heat-conducting area of the cubicle is:

$$A_e = 2HD + HW + DW$$

Estimate two of the cubicle dimensions – the height and depth, for instance. Calculate the width from:

$$W = \frac{A_e - 2HD}{H + D}$$

Inserting  $H = D = 0.7\text{m}$ , obtain the minimum width:

$$W = \frac{2.09 - (2 \times 0.7 \times 0.7)}{0.7 + 0.7} = 0.8 \text{ metres}$$

If possible, locate heat-generating equipment in the lower part of the cubicle to encourage internal convection. Otherwise, increase the height of the cubicle or install 'stirrer' fans.

### Installing in a ventilated cubicle

To calculate the volume of ventilating air, use the following procedure:

$$V = \frac{3.1 P_i}{T_i - T_{amb}}$$

where  $V$  = Air-flow in  $\text{m}^3/\text{hr}$

#### Example

To calculate the ventilation requirement for one CDE 750 Drive

$$P_i = 230\text{W}$$

$$T_i = 50^\circ\text{C}$$

$$T_{amb} = 30^\circ\text{C}$$

Then...

$$V = \frac{3.1 \times 230}{50 - 30} = 35.7\text{m}^3/\text{hr}$$

## Motor cooling

When a motor is driven at low speed, its internal cooling fan becomes less effective. If necessary, provide it with additional cooling (such as forced ventilation).

## Electrical Installation

### Warning Electric Shock risk

If the CDE Drive has been energised, the supply must be isolated *at least seven minutes* before work may continue. Refer to **Safety Information** on the inside front cover.

## Hazardous areas

A variable speed drive may invalidate a hazardous area certification (Apparatus Group and/or Temperature Class) of Ex-protected motors. Obtain approval and certification for the complete installation of motor and drive.

## Access to...

### Terminals

Remove the terminal cover by gripping its lower edge and pulling forward.

### Input Logic Polarity switch


Remove the control pod by gripping its top edge and pulling forward.

Re-fitting is the reverse process.

# Earthing

Connect the CDE Drive to system earth using the shortest possible wiring.

Earth impedance must conform to the requirements of industrial safety regulations. Earthing must be inspected and tested regularly.




CDE 75, 110, 150, 220

When using external braking resistor, remove link to disconnect internal braking resistor


Bottom view of: CDE 400, 550, 750, 1100 showing location of link for internal braking resistor

Link the **Line Protection Earth** on the power connector to the **Safety Earth** stud at the top of the CDE Drive.

# Power connections



Power connections to CDE 75, 110, 150, 220



Power connections to CDE 400, 550, 750, 1100

## Control connections

Terminal	I/O	Specification
<b>Analogue Inputs and Outputs</b>		
Status Relay Common	1	O Volt-free contacts. Contact ratings: 250V, 7A ac resistive Relay can be programmed (using parameter b5.20) to be energised when the CDE Drive is healthy or 'at speed'.
Status Relay N/open	2	
Status Relay N/closed	3	
0V Common	4	0V common.
Voltage Speed Ref Input	5	I Analogue voltage input, -10V to +10V. Zero speed at 0V. Input impedance 94kΩ. Alternatively, for unidirectional control, 0 to +10V. Resolution: 12 bit plus sign.
+10V Reference	6	O +10V Supply, 10mA max, internally protected.
Torque Ref Input	7	I Analogue voltage input -10V to +10V, zero torque at 0V. Input impedance 94kΩ. Resolution: 10 bit plus sign.
Current Speed Ref Input	8	I Analogue current input. 4 to 20mA, 20 to 4mA or 0 to 20mA input referenced to 0V common. Input impedance 100Ω. Resolution 10 bit plus sign.
<b>Digital Inputs and Outputs</b>		Note: Connections are given for negative logic polarity. If appropriate, move the Input Logic Polarity Link (under the Control Pod) for positive logic. The actions of the digital inputs are for Normal Mode. If Wireproof Mode is used, the alternative actions described on page 18 apply.
Motor Thermistor Input	9	I CDE Drive trips when thermistor value exceeds 3kΩ, and resets when value reduces to 1.8kΩ.
Frequency Input	10	I Frequency signal input for slaving or frequency control of the CDE Drive. 0 to +5V, 192kHz max.
0V Common	11	0V common.
External Trip Input	12	I Connect to 0V common via N/C contacts or conducting open collector. Momentarily open contacts to trip CDE Drive. 0V to +24V.
Reset Input	13	I Connect to 0V common via N/O contacts or open collector. Momentarily close contacts to reset CDE Drive; reset occurs on 'falling' edge. 0V to +24V.
Stop Input	14	I Connect to 0V common via N/C contacts or conducting open collector. Momentarily open contacts to stop CDE Drive. 0V to +24V.
Run Input	15	I Connect to 0V common via N/O contacts or open collector. Momentarily close contacts to start CDE Drive. 0V to +24V.
Local/Remote Input	16	I Connect to 0V common via contacts or open collector. Close contacts for remote reference. 0V to +24V.
Forward/Reverse Input	17	I Connect to 0V common via contacts or open collector. Close contacts to reverse motor. 0V to +24V.
Frequency Output Signal	18	O Analogue signal. -10V to +10V at 10mA max. Resolution: 10 bit plus sign. 0V = 0Hz, 10V = max frequency set using parameter p0.01.
Load Output Signal	19	O When b6.37 is set at 0: Analogue signal -10V to +10V at 10mA for 0 to 150% FLC. +ve for motoring forward and regenerating in reverse, -ve for regenerating forward and motoring in reverse. Resolution: 10 bit plus sign. Alternative function is selected with p6.28.
<b>Preset Speeds &amp; Status</b>		
Preset Speed 1 Input	20	I Connect to 0V by N/O contacts or open collector. To select a preset speed, see Preset Speed Selection table on page 17. 0V to +24V. Alternative function for terminal 22 is Jog Input, programmable using parameter b2.20.
Preset Speed 2 Input	21	
Preset Speed 3 Input	22	
Status Output	23	O 0V (250mA sink) to +24V (30mA source). Programmable using parameter p5.22 for Drive enabled, Load reached, Frequency reached, or x1 or x192 frequency output.
0V Common	24	0V common.
+24V Supply	25	O +24V supply at 200mA max, internally protected.


# Setting up to run

Configure the CDE Drive for either *Terminal mode* or *Keypad mode* of operation. The diagrams below show basic connections that need to be made to allow the CDE Drive to operate in either mode.

To operate the CDE Drive, certain parameters need to be adjusted. There are two types of parameter: numerical (**p**) parameters and bit (**b**) parameters. Numerical parameters allow adjustment of variables (eg. frequency limits); bit parameters allow selection of states (eg. selection of keypad mode or terminal mode).

Parameters are in nine menus. The menu number precedes the decimal point in the parameter number. After power-up, when **Mode** is pressed, parameter **p0.00** is displayed.

Normally, a motor thermistor must be connected to the CDE Drive to prevent **th** trips (see page 17). This can be disabled by setting **b6.22** at 1



The following are basic instructions for using the CDE Drive.

## Terminal mode

- 1 Ensure that the Speed Reference potentiometer is set at minimum.
- 2 Connect the CDE Drive to the supply.
- 3 Check the control pod display shows:

rdY

- 4 Close the **Run** switch.
- 5 Check the display shows the frequency.
- 6 Advance the Speed Reference potentiometer. Check the motor speed and displayed frequency change accordingly.
- 7 By default, the display shows frequency when the CDE Drive is running. To display Load (in Terminal mode only), press together the two keys:




## Keypad mode

- 1 Connect the CDE Drive to the supply.
- 2 Set parameter **b0.29** at 1 (See *List of Parameters*).
- 3 Check the display shows **rdY** alternating with the minimum frequency.
- 4 Press: ▲  
to raise the frequency. Check the motor speed increases. Reduce the speed by pressing: ▼  
When the minimum frequency (**p0.00**) is displayed, the CDE Drive stops.
- 5 If keypad mode is required the next time the CDE Drive is to be powered up, save parameters using **p0.33**.
- 6 When the CDE Drive is stopped, **rdY** and the minimum frequency are displayed alternately. When the Drive is running, the demanded frequency is displayed continuously.

- 7 If the CDE Drive trips when in Keypad Mode, the frequency demand and the trip are displayed alternately. To reset a trip, press together the two keys:



## Control pod



The control pod (see above) has a four-digit display. This display normally shows the *current status* (eg. rdY) of the CDE Drive, frequency, load current or a trip code. It can display instead:

### In View mode (display flashes)...

Menu and Parameter number

The value of a displayed parameter

You can scroll up or down to:

View the parameters in the selected menu

View menu number

### In Edit mode (display constant)...

Parameter value

Menu number

You can scroll up or down to edit parameter values or select a different menu number.

The **Mode** key is used to:

Change from View to Edit mode

Change from Edit to View mode

The ▲ & ▼ keys are used to scroll up or down.

## Parameters

### Display a parameter

- 1 Press the **Mode** key once. The display no longer shows the current status (eg. rdY). It now shows for one second a parameter number in the form of p0.01 or b0.20. (The display is now in View mode). The parameter value and the parameter number then alternate. After 8 seconds, the display returns to showing the current status.
- 2 To select a different parameter number, in Menu 0, press:




Either hold down or repeatedly press the key to scroll through the parameter set of Menu 0.

### Display a parameter in a different menu

- 1 When the display is alternately showing a parameter number and value, press:



continuously until the display shows:



(for Menu 0).

- 2 Before 8 seconds elapse, again press **Mode**. The display now goes constant, showing




The display is now in Edit mode.


- 3 To scroll through the menu numbers, press:



- 4 The menu number changes and is shown constant:



- 5 Before 8 seconds elapse, press **Mode**. The display now flashes:





- 6 To scroll through the parameter numbers in the displayed menu, press:

▲ or ▼

### Edit a parameter value

**Note** If security is set, parameter values cannot be edited unless the correct security code number is first entered. See *Security access* below.

The values of parameters may be changed when the CDE Drive is stopped or running.

- 1 Select the parameter to be edited by following the instructions in *Display a parameter*.
- 2 Press **Mode** once again. The display shows the parameter value constantly (without alternating with the parameter number).
- 3 Before 8 seconds elapse, press:

▲ or ▼

to increase or decrease the display reading. Pressing the key momentarily changes the value by plus or minus one least-significant digit. If the key is kept pressed, the displayed figure will increase or decrease rapidly. If a key is not pressed for 8 seconds, the display reverts to showing the current status of the CDE Drive.

### Save parameters

Most parameters are not saved at power down. Save parameters as follows:

- 1 Display the value of parameter p0.33.
- 2 Scroll through the values and stop when the display shows:

1

- 3 Press **Mode**. The parameters are saved and the display changes to:

0

alternating with:

p0.33

### Load default parameters

- 1 Display the value of parameter p0.33.
- 2 Scroll through the values and stop when the display shows:

255

- 3 Press **Mode**. The default parameters are loaded and the display shows the same as for saving parameters.

### Set up a security code

The CDE Drive is supplied with no security set up, (ie. security code = 0). There is no protection against unauthorised editing of parameters. To set up a security code, proceed as follows:

- 1 Display the value of p0.11.
- 2 Change the value to the desired security number.
- 3 Now display the value of parameter p0.33 and follow the procedure in *Save parameters* above.
- 4 Display the value of p0.11. Check that this reads:

0000

### Security access

To edit parameters when security is set up, proceed as follows:

- 1 Display parameter p0.11.
- 2 Change the displayed value to the security code number.
- 3 Display the parameter to be edited. Its value can now be changed.

## List of parameters

Parameters are saved according to the following letter:

- s At parameter save (using p0.33)
- n Never
- p At power down

Parameter		Default setting	Notes
<b>Menu 0 — Standard Parameters</b>			
p0.00	Minimum frequency	s 0.0	
p0.01	Maximum frequency	s 50.0	
p0.02	Acceleration time to 100Hz	s 5.0	Pro-rata to any other frequency.
p0.03	Deceleration time from 100Hz	s 10.0	Pro-rata from any other frequency.
p0.04	Motoring current limit	s 150	Set at 0 to 150% of rated Drive load current.
p0.05	Regenerating current limit	s 150	Set at 0 to 150% of rated Drive load current.
p0.06	Rated current	s 100	Set at rated load current of motor
p0.07	Voltage boost	s 3.0	
		Set maximum level of voltage boost for zero frequency at: 0 to 30% of rated voltage of motor (as entered in p0.12).	
p0.08	Slip compensation	s 0.0	
		Modifies output frequency of Drive to compensate for motor slip. Set at motor slip frequency for rated load current of motor (as entered in p0.06).	
p0.09	DC injection brake current	s 50.0	
		Set at 0 to 150% of rated load current of Drive. If this is set too low, the motor may not stop.	
p0.10	Serial address	s 11	Enter an identification number for serial communications.
p0.11	Security code	0	See <i>Set up security and Security access</i> above.

Note  
 The two types of standard ramp are:  
 Discontinuous — deceleration occurs in stages and so is not smooth; no setting up is required.  
 PID controlled — deceleration is continuous and smooth; setting up is required.

Parameter		Default setting	Notes
p0.12	Rated voltage	s 415	Enter rated voltage of motor.
p0.13	Rated frequency	s 50.0	Enter rated frequency of motor.
b0.20	Torque control	s 0	
		Set at 0 for frequency control. Set at 1 for torque control. If the Torque Control input is enabled (b6.27 = 1), the torque level is defined by the input voltage. -10V to +10V corresponds to -150% to +150% rated Drive torque. If b6.27 = 0, p6.12 defines the torque level.	
b0.21	Autostart	s 0	Set at 1 for Drive to start automatically when power is applied.
b0.22	Coast stop enable	s 0	Set at 1 to enable (over-rides DC injection brake)
b0.23	DC injection mode stop enable	s 0	Set at 1 to enable
b0.24	Fast ramp select (up and down)	s 0	
		Set at 0 for either type of standard ramp (see Note below left). The deceleration ramp rate is controlled to limit the DC bus voltage to the level set in p6.09. Discontinuous or PID controlled standard ramp is selected using b6.33. Set at 1 for fast ramp. The ramp rates are defined by the values of the acceleration and deceleration parameters, except when the Drive is stopping and b0.22 or b0.23 are set at 1.	
p0.25	Voltage control mode selector (See page 18)	s 0	Select:
		Auto-boost AUTO, where the boost is proportional to the load. Fixed boost Fd. Vector mode Vr_I : Rs test at initialisation. Vector mode Vr_S : Rs test at every start. Vector mode Vr : no Rs test.	
b0.26	Bipolar Speed Reference control	s 0	Set at 0 for unipolar control where speed control input is 0 to +10V. To reverse motor, close Forward/ Reverse switch.
b0.28	Load display	s 0	Set at 0 to display frequency.
b0.29	Keypad mode	s 0	Set at 0 for terminal mode.

Parameter		Default setting	Notes	
p0.30	Remote mode selector	s	4-20	Select:
			4-20mA 20-4mA 0-20mA, Fr s (frequency staving) Fr (frequency ratio input to define frequency demand) or HrES (high resolution frequency control)	
p0.31	Baud rate	s	4800	Select: 4800, 9600 or 19200
p0.32	Switching frequency	s	3	Select: 3, 6, 9, 12kHz
p0.33	Store parameters and load defaults	n		See Save parameters and Load default parameters above
<b>Menu 1 — Skip Frequencies</b>				
p1.00	Skip frequency 1	s	0	Must be lower than p1.01
p1.01	Skip frequency 2	s	0	Must be higher than p1.00 and lower than p1.02
p1.02	Skip frequency 3	s	0	Must be higher than p1.01
p1.03	Skip band 1	s	0	Select width of frequency band either side of related skip frequency through which the output frequency is required to pass but not stabilise.
p1.04	Skip band 2	s	0	
p1.05	Skip band 3	s	0	
<b>Menu 2 — Preset Speeds</b>				
p2.00	Preset frequency 1	s	0	Enter frequency in Hz. Negative values reverse the motor (The frequencies are selected using terminals 20, 21, 22.) See <i>Preset speed selection table</i> below).
p2.01	Preset frequency 2	s	0	
p2.02	Preset frequency 3	s	0	
p2.03	Preset frequency 4	s	0	
p2.04	Preset frequency 5	s	0	
p2.05	Preset frequency 6	s	0	
p2.06	Preset frequency 7	s	0	
p2.07	Jog Frequency	s	1.5	Enter frequency.
p2.08	Jog Boost Level	s	3.0	Enter boost level.
p2.09	High resolution frequency control	n	0	Enter frequency digits: XXX.X
p2.10	High resolution frequency control	n	0	Enter frequency digits: 0.0XX

Parameter		Default setting	Notes	
b2.20	Jog select	s	0	Set at 0 to use terminal 22 as Preset Speed Input 3. Set at 1 to use terminal 22 as Jog Input.
b2.21	Preset acceleration/ deceleration select	s	0	Set at 0 for ramps set in p0.02 and p0.03. Set at 1 for preset ramps set in Menus 3 and 4.
b2.22	Enable jog boost level	s	0	Set at 0 for normal boost. Set at 1 for boost set in p2.08.
<b>Menu 3 — Preset Acceleration Rates</b>				
p3.00	Preset acceleration 1	s	5.0	For each preset speed, enter value for preset acceleration to the preset speed.
p3.01	Preset acceleration 2	s	5.0	
p3.02	Preset acceleration 3	s	5.0	
p3.03	Preset acceleration 4	s	5.0	
p3.04	Preset acceleration 5	s	5.0	
p3.05	Preset acceleration 6	s	5.0	
p3.06	Preset acceleration 7	s	5.0	
p3.07	Jog acceleration	s	0.2	Enter value for acceleration to jog speed.
<b>Menu 4 — Preset Deceleration Rates</b>				
p4.00	Preset deceleration 1	s	10.0	For each preset speed, enter value for preset deceleration to the preset speed.
p4.01	Preset deceleration 2	s	10.0	
p4.02	Preset deceleration 3	s	10.0	
p4.03	Preset deceleration 4	s	10.0	
p4.04	Preset deceleration 5	s	10.0	
p4.05	Preset deceleration 6	s	10.0	
p4.06	Preset deceleration 7	s	10.0	
p4.07	Jog deceleration	s	0.2	Enter value for deceleration to jog speed.
<b>Menu 5 — Miscellaneous functions Auto-reset, threshold detectors, PI controller digital outputs, sequencing</b>				
p5.00	Number of automatic reset attempts	s	0	Default: 0 = disabled Set the number of auto-reset attempts from 1 to 5 after a trip.
p5.01	Reset delay	s	1.0	Set delay between auto-reset attempts from 1 sec to 5 secs.

Parameter		Default setting	Notes
p5.02	Load reached level	s 100	See p5.22
p5.03	Frequency reached level	s 50.0	See p5.22
p5.04	PI ramp	s 0.0	Set acceleration time to 100Hz and deceleration time from 100Hz — pro-rata for other frequencies
p5.05	PI proportional gain	s 0	Actual gain = p5.05 / 1000
p5.06	PI integral gain	s 0	Actual gain = p5.06 / 100
b5.20	Status Relay	s 0	Relay to be energised when: Set at 0 for Drive healthy. Set at 1 for Drive 'at speed'.
b5.21	Spinning motor enable	s 0	Set at 1 for Drive to 'catch' a spinning motor.
p5.22	Status Output selector	s Enbl	To select output function of terminal 23: Enbl — Drive enabled Frd — Frequency reached Lrd — Load reached Fout — Output frequency at: Drive frequency x1 or x192 (selected by b6.31).
b5.23	Dynamic V/f enable	s 0	Set at 1 to enable load-responsive V/f mode.
b5.24	Ramp down on trips cL, lt, Oh, th, thS	s 0	Set at 1 for Drive to ramp down when tripped.
p5.25	Wireproof sequencing select	s 0	Set at 0 for Standard mode (edge-triggered operation) Set at 1 for Wireproof mode (See page 17)
p5.26	PI enable	s 0	Set at 0 to by-pass the PI controller. Set at 1 to enable the PI controller.
p5.27	PI feedback selector	s 4-20	Select: 4-20 : 4-20mA from current speed ref I/P. Volt : -10V to +10V from torque ref I/P. Fr : 0 to 15497Hz from frequency input
b5.28	PI feedback invert	s 0	Set at 1 to invert the PI controller feedback signal

Parameter		Default setting	Notes
<b>Menu 6 — Advanced Parameters</b>			
p6.00	Vdc proportional gain	s 100	Use for mains loss control and for PID control of standard ramp braking.
p6.01	Vdc integral gain	s 400	
p6.02	Vdc differential gain	s 0	
p6.04	Current limit proportional gain	s 40	Use to set up frequency controlling current limit.
p6.05	Current limit integral gain	s 0	
p6.06	Frequency slaving numerator	s 1000	
p6.07	Frequency slaving denominator	s 1000	
p6.08	Stator resistance	p 0	Set: $\frac{\text{Stator resistance}}{\text{Per Unit resistance}}$  Per Unit resistance values: CDE75 0.1289Ω CDE110 0.0966Ω CDE150 0.0713Ω CDE220 0.0483Ω CDE400 0.0285Ω CDE550 0.0225Ω CDE750 0.0168Ω CDE1100 0.0129Ω
p6.09	Standard ramp voltage control level	s 700	Use to set the DC bus voltage level during standard ramp deceleration. Caution: When in PID control mode, do not set p6.09 below the likely level of DC bus voltage produced by the supply, since this may cause the motor to be accelerated to maximum speed instead of decelerated.
p6.10	S-ramp frequency band	s 0.0	
p6.11	Stop detection frequency	s 0.0	Stop is normally detected when the ramp output reaches zero. Use p6.11 to increase this level. When detected, the 1 sec stop period is initiated.
p6.12	Torque demand	s 0	Set torque level (only when b6.27 is set at 0)
p6.13	Magnetising current	p 55.0	Enter motor magnetising current as a percentage of the rated Load current of the CDE Drive.
b6.20	Mains loss detection disable	s 0	

Parameter		Default setting	Notes
b6.21	Mains loss forced stop select	s 0	
		Default: 0 for 'ride through' of short supply interruptions. Set at 1 for Drive to ramp down to stop when supply is interrupted.	
b6.22	Motor thermistor trip disable	s 0	
b6.23	High stability space vector modulation select	s 0	
		Set at 0 for conventional space vector modulation. Set at 1 to improve motor stability particularly on light loads.	
b6.24	Quasi-square mode enable	s 0	Set at 0 for PWM at all times. Set at 1 to disable PWM at full output voltage.
b6.25	Forward rotation disable	s 0	
b6.26	Reverse rotation disable	s 0	
b6.27	Torque Control Input enable	s 0	Set at 0 for control of torque using p6.12. Set at 1 for control of torque using terminal 7.
p6.28	Selector for analogue output on Terminal 19	s Load	Set at: LoAd: Load Vdc: dc link voltage, fullscale = 830V USEr: Level defined by p8.34.
b6.29	DC current injection when stopped for 1 sec.	s 0	Set at 0 for voltage control. Set at 1 for current control set in p0.09.
b6.30	High stability space vector modulation disable at stop	s 0	High stability space vector modulation can be noisy at low speeds. To disable at stop, set at 1.
b6.31	Master frequency x1 or x192 select	s 0	Set at 0 for x1. Set at 1 for x192.
p6.32	Automatic measurement of motor magnetising current enable	n 0	
b6.33	Standard ramp select	s 0	Set at 0 for discontinuous deceleration. Set at 1 for PID controlled deceleration. (See b0.20).
b6.34	Serial Comms two-wire mode enable	s 0	Set at 0 for 4-wire mode.

Parameter		Default setting	Notes
p6.35	Serial Comms mode select	s A	Set at A for ANSI serial comms.
p6.36	Serial Comms continuous transmit enable	s 0	
		Set at 0 for multi-drop systems where the transmitter is enabled only when the Drive sends data.	
b6.37	Load signal always positive for motoring	s 0	Set at:
		Set at 0 for output to be as described for Terminal 18 on page 8. Set at 1 for load signal to be always positive when motoring and always negative when regenerating.	
<b>Menu 7 — Fault log</b>			
p7.00	Last fault	p	Read only
p7.01	Previous fault	p	
p7.02	Previous fault	p	
p7.03	Previous fault	p	
p7.04	Previous fault	p	
p7.05	Previous fault	p	
p7.06	Previous fault	p	
p7.07	Previous fault	p	
p7.08	Previous fault	p	
p7.09	Previous fault	p	
<b>Menu 8 — Control/Status Parameters</b>			
b8.00	Drive disable	s 0	Set at 0 for Drive enabled. Set at 1 for Drive cannot be enabled.
b8.01	Display stop state	n 0	Read only — 0 = Run possible 1 = Run not possible
b8.02	Run control / status	n 0	
		When b8.10 is set at 0, b8.02 shows state of terminal 15 (Run Input). 1 = low for negative logic. When b8.10 is set at 1, terminal 15 has no effect and the Run function is controlled by b8.02	
b8.03	Reverse control / status	n 0	
		When b8.11 is set at 0, b8.03 shows state of terminal 17 (Reverse Input) 1 = low for negative logic. When b8.11 is set at 1, terminal 17 has no effect and the Reverse function is controlled by b8.03	

Parameter	Default setting	Notes
b8.04 Remote control / status	n 0	
		When b8.12 is set at 0, b8.04 shows state of terminal 16 (Remote Input) 1 = low for negative logic. When b8.12 is set at 1, terminal 16 has no effect and the Remote function is controlled by b8.04
b8.05 External trip control / status	n 0	
		When b8.13 is set at 0, b8.05 shows state of terminal 12 (Trip Input) 1 = low for negative logic. When b8.13 is set at 1, terminal 12 has no effect and the external trip function is controlled by b8.05
b8.06 Reset control / status	n 0	
		When b8.14 is set at 0, b8.06 shows state of terminal 13 (Reset Input) 1 = low for negative logic. When b8.14 is set at 1, terminal 13 has no effect and the Reset function is controlled by b8.06
b8.07 Preset frequency 1 control / status	n 0	
		When b8.15 is set at 0, b8.07 shows state of terminal 20 (Preset Speed 1 Input) 1 = low for negative logic. When b8.15 is set at 1, terminal 20 has no effect and the Preset freq. 1 function is controlled by b8.07
b8.08 Preset frequency 2 control / status	n 0	
		When b8.16 is set at 0, b8.08 shows state of terminal 21 (Preset Speed 2 Input) 1 = low for negative logic. When b8.16 is set at 1, terminal 21 has no effect and the Preset freq. 2 function is controlled by b8.08
b8.09 Preset frequency 3 control / status	n 0	
		When b8.17 is set at 0, b8.09 shows state of terminal 22 (Preset Speed 3 Input) 1 = low for negative logic. When b8.17 is set at 1, terminal 22 has no effect and the Preset freq. 3 function is controlled by b8.09
b8.10 Run parameter control select	s 0	
		Set at 0 for b8.02 to act as Run status (read only). Set at 1 for b8.02 to act as Run control.
b8.11 Reverse parameter control select	s 0	
		Set at 0 for b8.03 to act as Reverse status (read only). Set at 1 for b8.03 to act as Reverse control.

Parameter	Default setting	Notes
b8.12 Remote parameter control select	s 0	
		Set at 0 for b8.04 to act as Remote status (read only). Set at 1 for b8.04 to act as Remote control.
b8.13 External trip parameter control select	s 0	
		Set at 0 for b8.05 to act as External trip status (read only). Set at 1 for b8.05 to act as External trip control.
b8.14 Reset parameter control select	s 0	
		Set at 0 for b8.06 to act as Reset status (read only). Set at 1 for b8.06 to act as Reset control.
b8.15 Preset frequency 1 parameter control select	s 0	
		Set at 0 for b8.07 to act as Preset freq. 1 status (read only). Set at 1 for b8.07 to act as Preset freq. 1 control.
b8.16 Preset frequency 2 parameter control select	s 0	
		Set at 0 for b8.08 to act as Preset freq. 2 status (read only). Set at 1 for b8.08 to act as Preset freq. 2 control.
b8.17 Preset frequency 3 parameter control select	s 0	
		Set at 0 for b8.09 to act as Preset freq. 3 status (read only). Set at 1 for b8.09 to act as Preset freq. 3 control.
b8.18 Drive healthy	n 0	Read only
b8.19 Drive running	n 0	
b8.20 hxt active	n 0	
p8.22 Actual frequency	n	Read only
p8.23 Load level	n	
p8.24 DC link Volts	n	
p8.25 Heatsink temperature in °C	n	
p8.26 Number of reset attempts left for auto reset	n	
p8.27 User software version number digits 1 & 2	n	
p8.28 User software version number digit 3	n	
p8.29 Machine control software version number digits 1 & 2	n	
p8.30 Machine control software version number digit 3	n	

Parameter		Default setting	Notes
p8.31	Level of voltage speed ref input	n	Read only -10V to +10V = -999 to +999
p8.32	Level of torque input	n	Read only -10V to +10V = -999 to +999
p8.33	Level of current speed ref input	n	Read only 0 to 20mA = 0 to +999
p8.34	User analogue output level	n	If p6.28 is set at User, p8.34 defines the output level on Terminal 19: -10V to +10V = -999 to +999
p8.35	User trip	n	If p8.35 is set at less than 40, the trip associated with the number is displayed and the CDE Drive trips. If p8.35 is set at 40 to 69, trip is displayed and the CDE Drive trips. If p8.35 is set at 70, the CDE Drive resets if a trip has occurred.
p8.36	MD29 software version number	n	Read only Digits 1 & 2

Parameter		Notes
<b>Menu 9 — MD29 parameters</b>		
p9.00 to p9.04	s	Parameters with range: -999 to +999
p9.05 to p9.09	n	
p9.10 to p9.19	s	Parameters with range: 0 to 255
p9.20 to p9.39	s	Bit parameters

## Preset speed selection

Preset Speed			Terminal 22	Terminal 21	Terminal 20
b20 = 0	b20 = 1				
	When stopped	When running			
NSR	Stop	NSR	X	X	X
1	Stop	1	X	X	0
2	Stop	2	X	0	X
3	Stop	3	X	0	0
4	Jog	NSR	0	X	X
5	Jog	1	0	X	0
6	Jog	2	0	0	X
7	Jog	3	0	0	0

where: X = open circuit, 0 = connected to 0V (for negative logic polarity).  
NSR = Normal speed reference.

## Display messages

Display messages shown below in black are constant. Messages shown in grey are flashing.

### Healthy messages

<b>rdY</b>	Standby (in Terminal mode)
<b>rdY</b>	Standby (in Keypad mode)
<b>AcUU</b>	Mains loss
<b>dc</b>	Injection brake
<b>SCAN</b>	Spin start
<b>....</b>	100% Current exceeded

### Trip messages

The number given against each trip description is the value seen by Serial Comms in the trip log.

<b>---</b>	0 No trip
<b>cL</b>	1—Loss of current loop on Current Speed Ref I/P
<b>Et</b>	2—External trip has operated
<b>It</b>	3—Integrating overload (I xt)
<b>Oh</b>	4—Heatsink over-temperature
<b>OIAC</b>	5—Instantaneous AC trip
<b>OV</b>	6—DC Bus over-voltage
<b>Ph</b>	7—Supply phase loss
<b>PS</b>	8—Internal supply failure
<b>th</b>	9—Motor thermistor trip
<b>OldC</b>	10—Instantaneous DC trip
<b>EPS</b>	11—External 24V power supply fault

<b>UU</b>	13—DC Bus under-voltage
<b>Prc2</b>	19—Watchdog failure on MD29 or other application board
<b>rS</b>	21—Drive outputs are open circuit during stator resistance measurement
<b>trip</b>	40-69—Trip activated by setting p8.35 at 40-69. These appear in the trip log as tr40 to tr69
<b>HF</b>	Consult supplier if a code of this type appears

## Wireproof mode

When p5.25 is set at 1, the CDE Drive will run only when the **Stop** and **Reset** inputs are active, and either the **Run** or **Reverse** input is active. (An input is active when the switch is closed).

The CDE Drive continues running for 70ms after the **Run** or **Reverse** switch is opened to allow direction reversal without stopping.

The CDE Drive stops when either the **Stop** or **Reset** switch is opened, or the **Run** and **Reverse** switches are both open for at least 70ms.

## Voltage control

The voltage applied to the motor can be controlled in one of three ways:

### Fixed boost

Fixed V/f characteristic with fixed boost at 0Hz

### Auto-boost

Similar to fixed boost, except the amount of boost is load dependent

## Vector mode

The CDE Drive compensates for stator resistance by analysing the motor currents into vectors. To implement this type of control, the CDE Drive requires the values of the stator resistance and magnetising current. These values can either be entered manually or measured automatically by the CDE Drive.

### Stator resistance

The value is stored in p6.08.

Set p0.25 = Vr\_I to automatically measure the resistance at power-up only.

Set p0.25 = Vr\_S to automatically measure the resistance at power-up and each time the CDE Drive starts.

Set p0.25 = Vr to enter a value manually into p0.68 or to use the last automatically measured value.

Since stator resistance changes with operating temperature, it is advisable to set p0.25 at Vr\_S if possible.

### Magnetising current

Either manually enter the value into p6.13 or use the following procedure to set up the CDE Drive to automatically measure the magnetising current during commissioning. The magnetising current can be measured with the machine loaded or unloaded.

- 1 Set up the CDE Drive for the application (eg. ramp rates correctly set, etc).
- 2 Close the **Stop** switch.
- 3 Set p6.32 at 255. The CDE drive will run at half the rated frequency, measure the magnetising current, then stop. The value in p6.32 returns to 0. The measured value of the magnetising current is stored in p6.13 and saved at power-down.
- 4 If the motor speed is not stable during the measurement, repeat the test since the result may be incorrect.

Since the magnetising current remains constant, it is not necessary to make further measurements.



## Serial Communications

Serial communications can be used by a host computer or PLC to:

- Read and edit the values of parameters
- Control the CDE Drive

One host system may interface with up to 81 Drives when line buffers are used or 32 Drives without line buffers. The protocol is industry standard ANSI x 328-2.5-A4. The data format is 7 data bits, 1 start bit, 1 stop bit, and even parity.

### Connecting the CDE Drive


Serial Comms connector	
Pin	Function
1	0V isolated common
2	Tx non-inverted output
3	Rx non-inverted input
4	NC
5	NC
6	Tx inverted output
7	Rx inverted input
8	NC
9	NC

### Message structure

Messages consist of:

- Control characters
- Serial address code
- Parameter identifier
- Data field
- Block checksum (BCC)

The message structure is shown below.



### Control Characters

If a message is initiated from a keyboard, control characters may be entered by holding down the Ctrl key while pressing the key given in the last column of the table below.

Char-acter	Purpose	ASCII code (HEX)	Key
EOT	Reset Message begins End of transmission	04	D
ENQ	Enquiry Interrogating the Drive	05	E
STX	Start of text	02	B
ETX	End of text	03	C
ACK	Acknowledge (Message accepted)	06	F
BS	Backspace (Go to previous parameter)	08	H
NAK	Negative acknowledge (Message not understood)	15	U

### Serial address code

Each CDE Drive on a serial communications link, must have an individual address code. The required serial address code should be entered in p0.10. The code must have two digits, and the number 0 must *not* be used. The first digit defines the *group* (1 to 9); the second digit defines the *Drive number* in the group (1 to 9).

The code for an individual CDE Drive should be sent by the host as in this example:

CDE Drive address code: 28  
Address code to be sent by host: 2288

To address all the Drives in Group 2, the host would need to send:

2200

To address all CDE Drives on the serial comms link, the host would need to send:

0000

**Parameter identifier**

To address an individual parameter, the host needs to send a code that relates to the parameter number. For example:

To address - p0.01

Send - 0001

(Replace the **p** or **identifier** by the number **0**, and omit the decimal point).

**Data field**

Data are sent as numerical values with a negative polarity sign and decimal point when appropriate. The data field is of variable length, with a maximum of seven characters including the decimal point. The state of bit parameters is sent as numerical value **1** or **0**. For variable (**p**) parameters, having a series of options defined by character strings on the display (eg. p0.30), the first option (**4-20**) is set by sending **0**, the second option (**20-4**) by sending **1**, etc.

**Block checksum**

The block checksum character (BCC) is used to check that each message has not been corrupted when being sent. The BCC is a value that is calculated from the ASCII codes of the characters in the parameter and data fields.

The following example shows how the BCC is calculated.

A message for parameter **p2.09** contains the value **-47.6**. The parameter identifier is **0209** and the data field contains **-47.6**.

The ASCII codes (for the parameter identifier) are:

0 011 0000  
 1 011 0001  
 0 011 0000  
 9 011 1001


The first and second ASCII codes are compared in an **XOR** function. The result is **000 0010**.

This result is compared with the third ASCII code (011 0000) which produces the result **011 0010**. This number is then compared with the next ASCII code. The process is repeated until the final digit in the data field is reached, as shown below:

Character	ASCII code	XOR
0	0011 0000	
2	0011 0010	0000 0010
0	0011 0000	0011 0010
9	0011 1001	0000 0011
-	0010 1101	0010 0110
4	0011 1100	0001 0010
7	0011 0111	0010 0101
.	0010 1110	0000 1011
6	0011 0110	0011 1101
ETX	0000 0011	0011 1110
>	0011 1110	

**Note** If the decimal value is less than **32**, then **32** must be added. The resulting code is then used to derive the BCC.

Messages from host to interrogate the CDE Drive



## Messages from host to CDE Drive

Messages from the host to the CDE Drive are used to:

Interrogate the CDE Drive for values or states of parameters

Send a command to the CDE Drive

### Interrogating the CDE Drive

To find the value of a parameter, the host should send a message that is structured as shown at the foot of the previous page.

The data field is not used

The final control character should be:

ENQ (Ctrl E)

### Sending a command to the CDE Drive

To send a command, the message structure given at the foot of page 19 should be used.

Commands are used to:

Change the value of a parameter

Control operation of the CDE Drive

### Change a parameter value

To change a parameter, the message should contain the relevant parameter identifier. The data field should contain the required value.

For example, to set parameter p2.09 at -47.6Hz, send:

Parameter identifier 0209

Data field -47.6

To set b0.21 at 1, send:

Parameter identifier 0021

Data field 1

### Control the CDE Drive

To control operation of the CDE Drive, the message should contain the relevant control parameter identifier. The data field should contain the value relating to the required control state. For example, to start the CDE Drive, b8.02 must be set at 1. Send:

Parameter identifier 0802

Data field 1

To stop the CDE Drive, send:

Parameter identifier 0802

Data field 0

The control parameters are b8.02 to b8.09. These parameters are active only when the relevant *control select parameter* is set at 1. (See b8.10 to b8.17 in the *List of Parameters*).

## Messages from CDE Drive to host

Messages from the CDE Drive to the host are used to:


Reply to an interrogation (send a message containing the value of the parameter specified by the host)

Acknowledge a command from the host

### Replying to an interrogation

When the CDE Drive is interrogated for the value of a parameter, the CDE Drive sends a message in reply that contains the parameter

CDE Drive replying to an interrogation



identifier and, in the data field, the value of the parameter.

The structure of reply messages is shown in *CDE Drive replying to an interrogation* below.

**Acknowledging a command**

When a message has been sent by the host, the CDE Drive responds by sending an acknowledgement.

If the message was a command, the CDE Drive sends the reply message: **ACK**

If a command from the host is not understood, the CDE Drive sends the reply message: **NAK**

A message can be misunderstood because:

- Transmission was corrupted
- Message was incorrectly structured
- Requested value was out of range

If the specified parameter number is not recognised by the CDE Drive, the CDE Drive sends the reply message: **EOT**


**Other messages from host to CDE Drive**

Time can be saved by sending the control codes given below:


<b>NAK</b> (Ctrl U)	Repeat enquiry	Interrogate the CDE Drive repeatedly for the current value of the last specified parameter.
<b>ACK</b> (Ctrl F)	Next parameter	Interrogate the CDE Drive for the value of the next parameter in the list.
<b>BS</b> (Ctrl H)	Previous parameter	Interrogate the CDE Drive for the value of the previous parameter in the list.

To ensure that the correct Drive answers, a valid full-length read or write must occur before these codes will work.


**Structure of commands from host to CDE Drive**




**Messages from host to interrogate the CDE Drive**



**CDE Drive replying to an interrogation**









**Scaling that is applied in Scaling Blocks**

Input terminal	Input	Bipolar mode	Unipolar mode
Voltage speed ref input	-10V to +10V 0V to +10V	-max Hz to +max Hz	min Hz to max Hz
Current speed ref input as frequency demand	4 to 20mA 0 to 4mA	0Hz to max Hz	min Hz to max Hz
Current speed ref input as PI controller feedback	4 to 20mA	0Hz to max Hz	min Hz to max Hz
Frequency input	0 to 1648Hz	0Hz to max Hz	0Hz to max Hz
Torque input as PI controller feedback	-10V to +10V	-max Hz to +max Hz	-max Hz to +max Hz

CDE logic diagram (part 1)



CDE logic diagram (part 2)



**ARGENTINA - Buenos Aires** **Distributor**

**Euro Techniques SA** Tel & Fax: [54] 11 4331 7820  
 Peru 359-6to. Piso Of 603  
 (1067) Buenos Aires

**AUSTRALIA - Melbourne Application Centre**

**Control Techniques Australia Pty Ltd** Tel: [61] 3 973 81777  
 A.C.N. 003815281 Fax: [61] 3 972 3200  
 471 Mountain Highway After Hours: [61] 2 9963 5271  
 Bayswater  
 Victoria 3153

**AUSTRALIA - Sydney Drive Centre**

**Control Techniques Australia Pty Ltd** Tel: [61] 2 9838 7222  
 A.C.N. 003815281 Fax: [61] 2 9838 7764  
 16-18 Tucks Road After Hours: [61] 2 9963 5271  
 Seven Hills  
 (Sydney)  
 NSW 2147

**AUSTRIA - Linz Drive Centre**

**Control Techniques GesmbH** Tel: [43] 7229 789480  
 Traunferstrasse 109 Fax: [43] 7229 7894810  
 A-4052 Ansfelden After Hours: [43] 7215 3502

**BELGIUM - Brussels Drive Centre**

**Control Techniques NV/SA** Tel: [32] 2725 2721  
 Hoge Wei 1 Fax: [32] 2725 4940  
 1930 ZAVENTEM

**BRAZIL - Sao Paulo** **Distributor**

**ACIEL Comercio e Servicos LTDA** Tel & Fax: [55]11 5565 5798  
 Rua Nazare Rezak Farah 51  
 CEP 04367-050 Vila Santa Catarina  
 Sao Paulo - SP

**BRAZIL - Sao Paulo** **Distributor**

**Positronic Sistemas Industriais** Tel: [55]11 831 2677  
 Rua Bernardo Guimarães, 248 Fax: [55] 11 831 2678  
 05902-030 - V. Anastácio  
 Sao Paulo  
 SP, Brazil

**CANADA - Toronto Drive Centre**

**Control Techniques Canada** Tel: [1] 905 475 4699  
 9999 Highway 48 Fax: [1] 905 475 4694  
 Markham  
 Ontario L3P 3J3

**CENTRAL AMERICA** **Distributor**

**SEL Suministros Electricos** Tel: [504] 557 0657  
 Boulevard Juan Pablo II Fax: [504] 557 6195  
 2da Y 3era. Ave., S.E.  
 Apdo. Postal 1913, San Pedro Sula  
 Honduras, Central America

10.99

**CHILE - Santiago** **Distributor**

**Comercial Leroy Somer** Tel: [56] 2 2360001  
 Av. Providencia Fax: [56] 2 2363414  
 Piso3, Ofic. 4  
 Santiago 4

**CHINA - Shanghai Drive Centre**

**Control Techniques China** Tel: [86] 21 64085747  
 (E.E.S.S.Co) Fax: [86] 21 64083282  
 227 Caobao Road  
 Shanghai 200233

**COLOMBIA** **Distributor**

**Emerson Electric de Colombia Ltd** Tel: [57] 1 439 5470  
 106# 15-25, Lote 121 Fax: [57] 1 439 5417  
 Bodega #6  
 Zona Franca de Bogota

**COLUMBIA** **Distributor**

**Sistronic LTDA** Tel: [57] 92 661 5903  
 Av. 4 Norte No. 33AN-16 Fax: [57] 92 660 4407  
 Cali  
 Colombia

**CYPRUS - Limassol** **Distributor**

**Acme Industrial Electronic Services Ltd** Tel: [357] 5 332181/387047  
 23 Gropius St Fax: [357] 5 387781  
 PO Box 1983  
 Limassol

**CZECH REPUBLIC - Brno Drive Centre**

**Control Techniques Brno s.r.o** Tel: [420] 541 192111  
 Podnikatelska 2b Fax: [420] 541 192115  
 CZ61200 Brno After Hours: [420] 603 841 983

**DENMARK - Copenhagen Drive Centre**

**Control Techniques A.S.** Tel: [45] 4369 6100  
 Elektronvej 1 Fax: [45] 4369 6101  
 2670 Greve After Hours: [45] 4369 6100

**DENMARK - Århus (Mid Jylland) Application Centre**

**Control Techniques A.S.** Tel: [45] 8625 5755  
 Elkærvej 30 Fax: [45] 8625 1755  
 8230 Åbyhøj After Hours: [45] 4369 6100

**EGYPT - Cairo** **Distributor**

**Samiram** Tel: [202] 341 0849  
 45 Mohamed Mazahar Fax: [202] 342 1839  
 Zamalek  
 Cairo



**FINLAND - Helsinki Drive Centre**

Control Techniques SKS-oy  
 Martinkyäntie 50  
 PO Box 122  
 FIN-01721 VANTAA

Tel: [358] 985 2661  
 Fax: [358] 985 26823  
 After Hours: [358] 500 423271

**HUNGARY - Budapest Drive Centre**

Control Technika Hungary Kft  
 H1108 Budapest, Venyige u3  
 1475 Budapest, Pf.266

Tel: [361] 431 1160  
 Fax: [361] 260 5483

**FRANCE - Angouleme Drive Centre**

Leroy Somer  
 Usine des Agriers  
 16015 Angouleme Cedex

Tel: [33] 54564 5454  
 Fax: [33] 54564 5400

**ICELAND - Gardabaer****Distributor**

Samey HF  
 Lyngas 13  
 210 Gardabaer

Tel: [354] 510 5200  
 Fax: [354] 510 5201  
 After Hours [354] 510 5200

**GERMANY - Bonn Drive Centre**

Control Techniques GmbH  
 Meysstrasse 20  
 D53773 Hennef

Tel: [49] 2242 8770  
 Fax: [49] 2242 877277  
 Service (24hr): [49] 171 496 4777

**INDIA - Bombay Application Centre**

Control Techniques Elpro Automation Ltd,  
 406 Metro House  
 7 Mangaldas Road  
 Pune 411 001

Tel: [91] 20 631954/630917  
 Fax: [91] 20 603312

**GERMANY - Chemnitz Drive Centre**

Control Techniques GmbH  
 Röhrsdorfer Allee 14  
 D-09247 Röhrsdorf

Tel: [49] 3722 5203-0  
 Fax: [49] 3722 5203-30  
 Service (24hr): [49] 171 496 4777

**INDIA - Calcutta Application Centre**

Control Techniques India Ltd  
 Plot X-2 Block - EP  
 Sector-V  
 Salt Lake City  
 Calcutta - 700 091  
 West Bengal

Tel: [91] 33 3575302/3575306  
 Fax: [91] 33 3573435  
 After Hours: [91] 44 496 1083

**GERMANY - Darmstadt Drive Centre**

Control Techniques GmbH  
 Rodensteinstr. 19  
 D64625 Bensheim

Tel: [49] 6251 1770-0  
 Fax: [49] 6251 1770-98  
 Service (24hr): [49] 171 496 4777

**INDIA - Madras Drive Centre**

Control Techniques India Ltd  
 117B Developed Plot  
 Industrial Estate, Perungudi  
 Chennai 600-096  
 Madras

Tel: [91] 44 4961123/4961130  
 4961083  
 Fax: [91] 44 4961602  
 After Hours: [91] 44 496 1083

**GERMANY - Stuttgart Drive Centre**

Control Techniques GmbH  
 Max-Eyth Straße 23  
 D-71254 Ditzingen-Hirschlanden

Tel: [49] 7156 95560  
 Fax: [49] 7156 955698  
 Service (24hr): [49] 171 496 4777

**INDIA - New Delhi Sales Office**

Control Techniques India Ltd  
 4th Floor, Dheka House  
 Pusa Lane, 18/17 W.E.A. Karol Bagh  
 New Delhi  
 110 005

Tel: [91] 11 576 4782  
 Fax: [91] 11 576 782  
 After Hours: [91] 44 498 4868

**GREECE - Athens****Distributor**

Leroy Somer Hellas  
 Vasiladiou St 2  
 18540 Piraeus

Tel: [30] 1 42 25 815/816  
 Fax: [30] 1 42 25 817

**INDONESIA - Jakarta Application Centre**

P.T. Kontrol Teknik Indonesia  
 Jl. Kelapa Hibrida Raya  
 Blok PD14 No 14-15  
 Kelapa Gading Permai  
 Jakarta Utara 14250

Tel: [62] 21 4525146  
 Fax: [62] 21 4525142  
 After Hours: [62] 81 6870443

**HOLLAND - Rotterdam Drive Centre**

Control Techniques BV  
 PO Box 300  
 3360 AH Sliedrecht

Tel: [31] 1844 20555  
 Fax: [31] 1844 20721  
 After Hours: [31] 1844 20555

**INDONESIA - Surabaya Application Centre**

P.T. Kontrol Teknik Indonesia  
 J L Mayjen Sungkono  
 Komplek Wonokitri Indah  
 Blok S-16  
 Surabaya 60224

Tel: [62] 31 5682775/5623565  
 Fax: [62] 31 5622402  
 After Hours: [62] 81 6870443

**HONG KONG - Application Centre**

Control Techniques China PTE Ltd  
 20/F., Sing Pao Building  
 101 King's Road  
 North Point

Tel: [852] 2979 5271  
 Fax: [852] 2979 5220

**IRELAND - Dublin Drive Centre**

Electric Drives Ltd  
 Newbridge Industrial Estate  
 Newbridge  
 Co Kildare

Tel: [353] 45 433044  
 Fax: [353] 45 433622

**ISRAEL - Jerusalem****Distributor**

**DOR Drives Systems Ltd**  
 Talpiot Industrial Zone  
 PO Box 10542  
 Jerusalem 91102

Tel: [972] 2678 0984  
 Fax: [972] 2678 2457

**ITALY - Milan Drive Centre**

**Control Techniques SpA**  
 Via Brodolini 7  
 20089 Rozzano  
 Milan

Tel: [39] 02575 751  
 Fax: [39] 02575 12858  
 After Hours: [39] 02575 751

**ITALY - Vicenza Drive Centre**

**Control Techniques SpA**  
 Via Ortigara 13  
 36051 Creazzo (Vicenza)

Tel: [39] 0444 396200  
 Fax: [39] 0444 341317

**KOREA - Seoul Application Centre**

**Control Techniques Korea**  
 7th Fl, Cheong Lim Bldg. #38-30  
 SamSung-Dong, Kangnam-Ku  
 Seoul

Tel: [82] 2 3445 6183/84/85  
 Fax: [82] 2 3445 6181  
 After Hours: [82] 2 3445 6183

**MALAYSIA - Kuala Lumpur Drive Centre**

**Control Techniques (Malaysia) Sdn Bhd**  
 11 Jalan PJS 11/18  
 Bandar Sunway  
 46150 Petaling Jaya, Selangor Darul Ehsan

Tel: [60] 3734 9776  
 Fax: [60] 3733 9592  
 After Hours: [60] 10 333 8355

**MEXICO****Distributor**

**MELCSA**  
 Industria No. 25, Colonia Nextengo  
 Azcapotzalco  
 D.F. 02020  
 Mexico

Tel: [52] 5 561 1312  
 Fax: [52] 5 352 7255

**MEXICO**

**Servitech, S.A. de C.V.**  
 Av. A Lopez Mateos No. 8  
 Col. Francisco Villa,  
 Tlalnepantla,  
 Edo de Mex. C.P. 54049  
 Mexico

Tel: [52] 5 398 3380/9591  
 Fax: [52] 5 397 0982

**MOROCCO - Casablanca****Distributor**

**Leroy Somer Maroc**  
 Angle Rue El Gara & Rue El Haouza  
 Oukacha  
 Roches Noires  
 Casablanca

Tel: [212] 2 354948/354772  
 359677/359680  
 Fax: [212] 2 354956

**NEW ZEALAND - Napier****Distributor**

**Vectron Technologies Ltd**  
 PO Box 342  
 Napier

Tel: [64] 6843 1400  
 Fax: [64] 6843 0398

**NORWAY - Oslo Application Centre**

**Control Techniques Norway AS**  
 Ingv. Ludvigsensgt 23  
 PO Box 7044  
 N-3007 Drammen

Tel: [47] 32 23 5100  
 Fax: [47] 32 23 5101  
 After Hours: [47] 92 22 3292

**PAKISTAN - Lahore****Distributor**

**Arden Engineering & Automation (Pvt) Ltd**  
 11, Canal Park  
 Gulberg 11,  
 Lahore 54660

Tel: [92] 42 5710811/873429  
 Fax: [92] 42 5712798

**PERU - Lima****Distributor**

**Procesos Industriales Aplicados S.A.**  
 La Paz #200 Santa Patricia  
 La Molina  
 Lima. 12

Tel: [51] 1 349 5402/03  
 Fax: [51] 1 348 7331

**PHILIPPINES - Manila****Distributor**

**Gotesco Marketing Incorporated**  
 5th Floor Ever-Gotesco Corporate Centre  
 1962 Bilibid Viejo Cor G.Puyat Streets  
 Quiapo  
 Manila

Tel: [63] 2 733 8820  
 Fax: [63] 2 734 4997

**POLAND - Torun****Distributor**

**Apator SA**  
 Zolkiewskiego 13/29  
 87-100 Torun

Tel: [48] 56 61 91 111  
 Fax: [48] 56 61 91 312

**PORTUGAL - Porto****Distributor**

**Harker Sumner S.A.**  
 Drives & Automation Division  
 Zona Industrial da Maia 1-Sector X  
 4470 Barca

Tel: [351] 29478090  
 Fax: [351] 29478098

**REP. OF S. AFRICA - Johannesburg Drive Centre**

**Siliconics (Pty) Ltd**  
 PO Box 3215  
 Honeydew 2040  
 Johannesburg

Tel: [27] 11 462 1740  
 Fax: [27] 11 462 1941  
 After Hours: [27] 11 462 1740

**RUSSIA - Moscow Application Centre**

**Control Techniques Moscow**  
 Malaya Trubetskaya ul.,8  
 Korpus B, 11th Floor  
 119881, Moscow

Tel: [7] (095) 232947  
 Fax: [7] (095) 956 4862

**SAUDI ARABIA****Distributor**

**A. Abunayyan Elec. Corp.**  
 PO Box 321  
 Riyadh 11411

Tel: [966] 1 47 79 111  
 Fax: [966] 1 47 93 312

## SINGAPORE Drive Centre



Control Techniques Singapore Pte Ltd  
438B Alexandra Road #02-08  
Alexandra Technopark  
Singapore 119968

Tel: [65] 271 6377  
Fax: [65] 272 1302

## THAILAND - Bangkok Drive Centre



Control Techniques Thailand Ltd  
99/71-72 Prachachuen Road  
Ladyao, Jattujak  
Bangkok 10900

Tel: [66] 2580 7644  
Fax: [66] 2591 4559  
After Hours (Sales): [66] 1443 4095-7  
Services: [66] 1443 4098

## SLOVENIA - Ljubljana

### Distributor

PS Logatec  
podjetje za projektiranje in izdelavo  
strojev, doo, Kalce 38B  
SI-1370 Logatec

Tel: [386] 61 790200/205  
Fax: [386] 61 790204

## TURKEY - Istanbul Drive Centre



Control Techniques Endustriyel  
Kontrol Sistemleri  
Sanayii Ve Ticaret A.S.  
Kayisdagi Cad, Poyraz, Sok, Er-Togay Is Merkezi 4/24  
81040 Kadikoy, Istanbul

Tel: [90] 216 4182420  
Fax: [90] 216 4182423  
After Hours: [90] 216 418 2420

## SPAIN - Barcelona Drive Centre



Control Techniques Iberia S.A  
Carrer de Llobregat, Nave 8  
Poligono Industrial El Pla  
08750 Molina de Rei  
(Barcelona)

Tel: [34] 93 680 1661  
Fax: [34] 93 680 0903/0763/2823  
After Hours: [34] 610 554 540

## U.A.E. - Dubai

### Distributor

Leroy Somer Middle East  
Division of Emerson M.E. Inc.  
PO Box 17034 - Jebel Ali  
Dubai

Tel: [971] 4 838 650  
Fax: [971] 4 838 651

## SPAIN - Bilbao Application Centre



Control Techniques Iberia S.A  
Askatasun Etorbideo, 18 Bajo  
48200 Durango - Vizcaya

Tel: [34] 94 620 3646  
Fax: [34] 94 681 1406

## U.K. - Telford Drive Centre



Control Techniques  
Stafford Park 4  
Telford  
Shropshire  
TF3 3BA

Tel: [44] 1952 213700  
Fax: [44] 1952 213701  
After Hours: [44] 1952 213700

## SPAIN - Valencia Drive Centre



Control Techniques Iberia S.A  
Doctor Fleming 10  
46930 Quart de Poblet  
Valencia

Tel: [34] 96 154 2900  
Fax: [34] 96 153 2906

## U.K. - Leeds Drive Centre



Control Techniques  
Latchmore Industrial Park  
Lowfields Road  
Leeds, West Yorkshire  
LS12 6DN

Tel: [44] 113 2423400  
Fax: [44] 113 2423892  
After Hours: [44] 113 2423400

## SWEDEN - Stockholm Application Centre



Control Techniques Sweden AB  
Gränsbövägen 6  
152 42 Södertälje

Tel: [46] 8 554 241 00  
Fax: [46] 8 554 241 20

## U.K. - Luton Drive Centre



Control Techniques  
Sundon Business Park  
Dencora Way, Luton  
Beds LU3 3HP

Tel: [44] 1582 567700  
Fax: [44] 1582 567703  
After Hours: [44] 1582 567700

## SWITZERLAND - Zurich Drive Centre



Control Techniques A.G.  
Lindächerstrasse 1  
CH-5413 Birmenstorf  
Zurich

Tel: [41] 56 201 4242  
Fax: [41] 56 201 4243  
After Hours: [41] 79 3578 683

## U.K. - Warrington Application Centre



Control Techniques  
224 Europa Boulevard  
Gemini Business Park  
Warrington  
Cheshire  
WA5 5TN

Tel: [44] 1925 413537  
Fax: [44] 1925 242808  
After Hours: [44] 113 2423400

## SWITZERLAND - Lausanne Application Centre



Control Techniques A.G.  
PO Box 224  
Rue de Centre 16  
CH-1023 Crissier

Tel: [41] 21 634 0408  
Fax: [41] 21 635 8596  
After Hours: [41] 79 3578 683

## URUGUAY - Montevideo

### Distributor

Secoin S.A.  
Gral Aguilar 1270 Bis  
C.P. 11800  
Montevideo

Tel: [5982] 2093815/2030850  
Fax: [5982] 209 2584

## TAIWAN - Taipei Application Centre



Control Techniques Taiwan  
5th Floor, No. 2 Jen Ai Road  
Section 4  
Taipei  
Taiwan R.O.C

Tel: [886] 22 3259555  
Fax: [886] 22 7059131

## U.S.A. - Charlotte Application Centre



Control Techniques Drives Inc.  
2716 Interstate Street  
Charlotte  
North Carolina 28208

Tel: [1] 704 393 3366  
Fax: [1] 704 393 0900  
After Hours: [1] 716 692 2442

### **U.S.A. - Chicago Drive Centre**



**Control Techniques Drives Inc.** Tel: [1] 630 893 5249  
95 Brandon Court Fax: [1] 630 893 4156  
Glendale Heights  
Illinois 60139

### **U.S.A. - Cleveland Drive Centre**



**Control Techniques Drives Inc.** Tel: [1] 440 717 0123  
6900 Southpointe Parkway Fax: [1] 440 717 0133  
Brecksville  
Cleveland,  
Ohio 44141

### **U.S.A. - Dallas Drive Centre**



**Control Techniques Drives Inc.** Tel: [1] 972 783 1831  
1226 Exchange Drive Fax: [1] 972 783 9978  
Richardson After Hours: [1] 800 759 0664  
Texas 75081

### **U.S.A. - Providence Drive Centre**



**Control Techniques Drives Inc.** Tel: [1] 401 333 3331  
4 Blackstone Valley Place Fax: [1] 401 333 6330  
Lincoln After Hours: [1] 401 333 0080  
Rhode Island 02865

### **VENEZUELA**


#### **Distributor**

**Emerson Electric CA** Tel: [58] 2 237 7522  
Avenida Don Diego Cisneros Fax: [58] 2 238 9023  
(ppA1 De Los Ruices)-Edificio Stemo  
Piso 1, Aptdo 75748  
Caracas 1071-A

### **VIETNAM - Ho Chi Minh Application Centre**



**Control Techniques** Tel: [84] 8 842 5157  
**Vietnam Co Ltd** [84] 8 849 1980  
(Ho Chi Minh) Fax: [84] 8 842 5157  
70A Truong Cong Dinh St, Ward 13  
Tan Binh District, Ho Chi Minh City



0427-0013